


Locking Device Installation

Step 1



Remove handle from ball valve

Step 2



Mount collar to ball valve

Step 3



Insert mounting screw into locking stem

Step 4



Mount locking stem into collar

Step 5



Tighten mounting screw

Step 6

Mounting handle